

Installation instructions : SIRIUS SQUARE PLINTH LIGHT SY7523NW/WW - 3 LT KIT SY7524NW/WW - ADD ON LIGHT

Thank you for purchasing this SycamoreLED.com product. Please make sure instructions are followed carefully prior to and during installation and product is not altered, otherwise warranty may not be valid. For technical support or warranty information please visit www.sycamoreLED.com, or call our dedicated technical helpline +44 (0) 113 2866686.

IMPORTANT—Please read prior to installation

- 1) Please read these instructions carefully before commencing any work
- 2) Please retain these instructions for future reference
- 3) It is strongly recommended that this unit is installed by a qualified electrician in accordance with the IEE wiring regulations and building regulations
- 4) To prevent electrocution switch the power off at the mains supply before installing or maintaining this fitting
- 5) Ensure others cannot restore the electrical supply without your knowledge
- 6) The PSU must be rated 12VDC and be compatible with the pre-wired connector system of this product
- 7) Never exceed the wattage stated

SPECIFICATION

Item	Rated voltage/V	Rated power/W	LEDs per fitting	IP Rating	Protection
SY7523/24	12v DC	1.5w per fitting	16	20	CLASS III

PRE - INSTALLATION

- 1) Please prepare all the parts and tools which the installation needs.
- 2) Select location for lights ensuring that the driver is accessible to connect into
- 3) Turn off power before installation

INSTALLATION

- 1) Drill suitable size hole in chosen location(s) to enable cable to be routed to the driver
- 2) Put wire through the hole, and connect to the driver distribution block using the fast fit connector system
- 3) Connect the mains power to the 12VDC driver, check operation
- 4) Ensure the body of the lamp is securely fixed onto the face of installation using the self adhesive pad.

sycamore SY7523/7524



This luminaire contains built-in LED lamps.



} LED

The lamps cannot be changed in the luminaire.

874/2012

