


Installation instructions : Solaris Square Diffused/Rectangle Diffused Light SY8950 / SY8951

Thank you for purchasing this SycamoreLED.com product. Please make sure instructions are followed carefully prior to and during installation and product is not altered, otherwise warranty may not be valid. For technical support or warranty information please visit www.sycamoreLED.com, or call our dedicated technical helpline +44 (0) 113 2866686.

IMPORTANT—Please read prior to installation

- 1) Please read these instructions carefully before commencing any work
- 2) This product must be installed by a qualified electrician in accordance with the current IEE wiring regulations
- 3) To prevent electrocution switch the power off at the mains supply before installing or maintaining this fitting
- 4) Ensure others cannot restore the electrical supply without your knowledge
- 5) The PSU must be rated 12VDC and be compatible with the pre-wired connector system of this product
- 6) Never exceed the wattage stated

DIAGRAMS



INSTALLATION

- 1) Choose desired location for light and ensure cable can be connected to PSU
- 2) Screw light into position using screws provided and make sure they are fitted square to the cabinet/shelf
- 3) Connect into PSU using fast fit connector
- 4) Check operation of the light fitting

CARE IN USE

- 1) Please note this fitting has non replaceable parts
- 2) Always switch off or disconnect from the mains when cleaning the product.
- 3) We recommend cleaning with a soft dry cloth. Do not use scourers, abrasives or chemical cleaners.

NOTES

- 1) This version of the popular Solaris Square/Recti, features a diffused cover meaning no visible LED points

